

USER’S- HANDLER’S GUIDE

Thank you for your confidence and your decision to purchase our bathroom furniture. The product meets the requirements of MSZ EN 14749:2005 standard.

Important! To avoid incorrect installation, improper use and handling we enclose an assembly and users-handlers’ guide to each of our products, please follow instructions included in guide in your own interest because we do not provide guarantee for faults arising from installing, use or handling products differently from instructed in assembly and user’s -handler’s guide.

Please keep the guide enclosed to the product carefully and study it in detail.

Delivery

Fix the product in each case properly in order to avoid damage in structure and quality of furniture. Warranty does not apply to faults and damage made during delivery.

Packaging

Remove packaging material and protection foil from the surface of furniture without damaging it before use then destroy the packaging or keep it away from infants and children.

Assembly instructions

Inaccurate mounting of furniture might cause structural and functional faults, so keep to instructions included in assembly and users’ – handlers’ guide carefully. Before mounting always make sure of having perfect vertical or horizontal walls (use spirit level to check). In case your wall is curved, correct unevenness with the help of fixing points.

IMPORTANT:

- Place furniture on firm, horizontal, flat floor at least 50 cm from radiant heaters.
- Fix furniture only onto load-bearing building structure, fasteners (wall-plug and screw) and tools used during fixing must be chosen according to masonry.
- Fix furniture only on flat- surface wall, if furniture is fixed on curved or uneven wall doors and drawers cannot be moved properly, basin might sway and mirror might come off from cabinet.
- With the help of adjustable furniture legs stand furniture into horizontal position, if you miss it basin might sway, doors and drawers cannot be moved properly.
- To avoid injury of furniture legs lift furniture when moving and do not push or pull it.

Warranty does not apply to faults arising from inaccurate mounting and fixing. To avoid such problems installing, establishing electric and water connection must be done by a qualified trades mechanic.

Cleaning

1. Cleaning mirrors and glass surfaces

- For cleaning mirrors and glass surfaces use only and exclusively wet leather or dry cloth suitable for this purpose.
- Difficult stains (remains of cosmetics, fat etc.) have to be cleared away at once then dried wipe with a clean cloth.
- Be careful not to leave drops on the sides, corners and back sides of mirrors and glass surfaces because of possible crusts which might damage the surface.
- Avoid using commercially available glass and window cleaners (with acidic or alkaline chemicals) because they might cause damage to silvering.
- The use of not proper cleaning utensils (scrubbing brush, scourer), and not proper detergents (chemically aggressive, especially chemicals containing acid, alkaline, silicone and alcohol such as Domestos, Clean, descaler, hydrochloric acid) might cause damage to silvering on mirror surface, mirror and furniture might get discoloured. For these faults guarantee cannot be validated.
- Try your detergent before use on a neutral surface.
- Lower part of painted glass surface must be cleaned with dry soft cloth. Avoid chemically aggressive detergents and utensils because paint might get removed because of their use.

2. Cleaning basins

2.1 Glass and synthetic ceramic basin

- Glass and synthetic ceramic basin must be wiped with soft wet cloth, then wiped dry with a lintfree cloth.
- Try your detergents on a neutral surface before use.
- Lower part of painted glass basin must be cleaned with dry soft cloth, avoid chemically aggressive detergents and utensils because paint might get removed because of their use.
- The use of not proper cleaning utensils (scrubbing brush, scourer), and not proper detergents (chemically aggressive especially chemicals containing acid, alkaline, silicone and alcohol e.g. Domestos, Clean, descaler, hydrochloric acid) might cause damage to basin surface, basin might get discoloured. For these faults guarantee cannot be validated.

2.2 Ceramic basin

- For cleaning ceramic basin use mild cleaning fluid. Avoid the use of chemically aggressive substances and scourer which might cause damage and scratches on the surface of basin. Avoid the use of descalers.
- Try your detergents on a neutral surface before use.
- The use of not proper cleaning utensils (scrubbing brush, scourer), and not proper detergents (chemically aggressive especially chemicals containing acid, alkaline, silicone and alcohol such as Domestos, Clean, descaler, hydrochloric acid) might cause damage to basin surface, basin might get discoloured. For these faults guarantee cannot be validated.
- Surface of basin might get injured by metal and hard-material objects, leaving crack lines and scratches (wedding ring, watch strap). These injuries can only be corrected by using polishing paste.

3. Cleaning furniture

- For cleaning cabinets, wooden, plastic and varnished surfaces and drawers use soft, clean cloth and non-scrubbing, household cleaning fluids (furniture care products).
- After cleaning wipe furniture dry in each case.
- In case of using too wet cloth water gets into points, which might cause curling and humps on surface of furniture.
- Avoid the use of strong, acidic chemicals, scrubbers, silicone wiper, wax, hard sponge and steam cleaner because the surface of furniture might get discoloured if using not proper detergents. For difficult stains use soft wiping cloth.
- Try your detergents on a neutral surface before use.
- Furniture might get discoloured on exposure to sunshine and extreme heat.

4. Cleaning faucets

- Try your detergents on a neutral surface before use.
- Avoid chemically aggressive detergents and utensils. Use natural cleaning materials such as sodium bicarbonate or lemon.
- Do not spray detergent directly on tap but on a wet cloth and then start cleaning. Detergent must be removed from tap in each case then tap must be wiped dry with dry cloth.
- Wipe taps dry after each use.

5. Cleaning hinges

- Use dry soft cloth to wipe, do not use detergent.

For faults listed above guarantee cannot be validated.

WARNING! AFTER CLEANING THE ROOM AND FURNITURE WITH DESCALER (TAP, BASIN, COVERS) ITS FUME MIGHT ALSO CAUSE DAMAGE TO FURNITURE IF IT IS NOT REMOVED FULLY.

- ON SURFACE OF MIRROR AND GLASS (DAMAGE TO SILVERING)
- ON SURFACE OF BASIN (DISCOLOURING)
- ON SURFACE OF FURNITURE (DISCOLOURING, SURFACE DAMAGE).

USER’S- HANDLER’S GUIDE

For faults and changes (discolouring, silvering, surface damage) arising from the use of unsuitable cleaning utensils (scrubbing brush, scourer), and unsuitable detergents (chemically aggressive especially chemicals containing acid, alkaline, silicone and alcohol such as Domestos, Clean, descaler, hydrochloric acid) guarantee cannot be validated.

Use of furniture and basin

Our bathroom furniture is suitable into bathrooms with normal climate even if humidity is temporarily higher (more than 90%), which can be improved by ventilation.

Tboss Ltd produces furniture of two different grades of water resistance.

1. Moderately splashproof

The material of the product is laminated blockboard with edge protection 0.4-2 mm ABS. Furniture in this category is splashproof which means if it is exposed to water you must wipe it dry immediately (especially carefully at edge protection areas). Otherwise furniture might suffer damage in structure. Recommended to use in sanitary units with big floorspace where furniture is not exposed directly to water (e.g. shower), humidity is constantly not higher than 65% and temperature is between 15-25 C.

2. Moderately waterproof

The material of the product is vacuum-pressed MDF. Furniture in this category do not get damaged from water splash, but furniture must be wiped dry after use because permanent exposure to water might cause damage in structure. Recommended to use in sanitary units with small floorspace where might get exposed to water splashes. Humidity in room might temporarily reach 90% and ideal temperature is 15-25 C.

IMPORTANT! WITH FURNITURE PLACED NEXT TO BATH OR SHOWER BE ESPECIALLY CAREFUL TO KEEP FURNITURE DRY.

Because of surface damage caused by too much moisture – especially at edges of cabinets – complaints cannot be accepted and warranty does not apply to such cases!

Load capacity:

- Furniture and drawers are loadable up to max. 25 kg evenly spread on surface.
- Upper cases with mirror are loadable up to max. 4 kg. Small cases and shelves are suitable for storing only toiletry products.
- Basins are especially sensitive to sudden temperature changes. To avoid cracks and breakage do not put deep-frozen drinks and hot pots on the basin.
- Be careful not to expose basin to mechanical impact (you must not sit or stand on it, drop perfume

glass) because it might cause crack on surface. For such faults guarantee cannot be validated.

- On basins roughness in places out of sight are features of material caused by moulding process, they are of no practical importance, complaints cannot be accepted because of them.

For faults originating from cases of improper use listed above guarantee cannot be validated.

The use of lamps and lamp bodies

- Electric connection must be established for a network with electric shock protection relay, installation must be done by a qualified trades mechanic.
- In a network without EV relay the lamp and transformer might get damaged because of possible overvoltage.
- Lamps, lighting bodies and other electronic parts were designed for household use (2-4 hours a day). In case of constant overload light source might go wrong, blow (light left switched on for night).
- Light bodies are tested in each case before packaging the furniture!
- Overload can be identified by follow-up testing!

For failure arising from improper installation or use warranty cannot be validated.

ASSEMBLY GUIDE / 1

Before mounting always make sure of having perfect vertical or horizontal walls (use spirit level to check). In case your wall is curved, correct unevenness with the help of fixing points to provide best operation of hinges and cabinets. Furniture fixed onto a not flat (curved) wall might cause damage to structure and bad functioning:


- door fronts in incorrect position,
- swaying basin,
- badly functioning drawer hinge.

Guarantee does not apply to faults arising from installing and fixing incorrectly. To avoid such problems installing must always be done by a qualified trades mechanic.

WARNING!

If furniture falls over it might cause accident. To avoid this furniture must be fitted to wall properly. Accessories needed for fitting are not included in packaging, because different fixing tools are needed for different kinds of wall.


Always choose fittings suitable for the type of wall. To find suitable fasteners ask for help in bathroom furniture shops.




ASSEMBLY GUIDE / 2

FIXING THE CABINET

Adjust furniture to vertical and horizontal directions in order to make hinges work properly. Fix bathroom furniture only onto totally vertical and flat wall!




Electric connection must be established for a network with electric shock protection relay only, installation must be done by a qualified trades mechanic.




PRODUCED AND DISTRIBUTED BY
Tboss Ltd.

1095 Budapest Soroksári út 5.
Mailing address: 8002 Székesfehérvár, Pf.: 205.
Phone: + (36-20)484-25-55
E-mail: info@tboss.hu


TAKING OUT/PUTTING IN/ ADJUSTING DRAWERS



- 1.TAKING OUT A SOFT-CLOSE TANDEM BOX DRAWER
- 1.A PULL OUT DRAWER UP TO 50%. 1.B PRESS BUTTON CIRCLED ON BOTTOM OF DRAWER AS FAR AS COLLISION ON BOTH SIDES, THEN LIFT DRAWER FROM TRACK.




2. LOCATING FURNITURE ON THE WALL
- 2.A FITTED FURNITURE MUST BE IN TOTALLY HORIZONTAL POSITION TO MAKE HINGES WORK PERFECTLY.




3. INSTALLING/ADJUSTING A SOFT-CLOSE TANDEM BOX DRAWER

- 3.A
- 
- PULL OUT DRAWER TRACK UP TO 100%.

- 3.B WITH SCREWS ON DRAWER SIDE (IN CASE OF ADJUSTING TO THE RIGHT OR LEFT: ON BOTH SIDES) DRAWERS CAN BE ADJUSTED.
- 1.- RELEASING FIXER (WITH SOME PRODUCTS ALSO ON BOTTOM OF DRAWER)
- 2.- ADJUSTING TO THE RIGHT OR LEFT
- 3.- ADJUSTING UP OR DOWN
- 4.- TIGHTENING FIXER



TANDEM BOX HINGES
INSTALLING/UNINSTALLING



Name and address of enterprise:	
Name of product:	
Type of product:	
Serial number of product (if there is any):	
Name and address of producer:	TBoss Ltd. 1095 Budapest Soroksári út 5.
Date of purchase:	
Date of delivery to customer or (if it is done by the enterprise or its representative) installation date (appropriate must be underlined)	

- INFORMATION ON WARRANTY RIGHTS
- The warranty period
- Furniture purchased under a consumer contract and shown on this warranty card is subject to Government Decree 151/2003 (IX.22.), paragraph 2, sub-paragraph (1), *appendix 23. If the conditions specified in the Instructions for Use and Handling are observed, we will undertake a one-year warranty. Failure to meet the deadline will result in disqualification. The warranty period begins with the delivery of the furniture to the consumer or, if the commissioning is carried out by the company or its agent, begins on the day of commissioning.
- The warranty period does not include the part of the repair time during which the product cannot be used as intended. The warranty period starts again in the event of replacement (repair) of the product or part of the product with respect to the replaced (repaired) product (part of the product) and in respect of a defect resulting from the repair.
- The warranty does not affect the exercise of your statutory rights, in particular the warranty on products and parts, and on indemnity. In the event of a defective product, the product warranty claim is governed by Act V of 2013, paragraph 6:168. A product is defective if it does not comply with the quality requirements in force when the product was placed on the market by the manufacturer (distributor) or if it does not comply with the manufacturer's (distributor's) description of the properties.
- Based on these, please make sure that the properties of the product are specified and guaranteed by the manufacturer (distributor) in the product description before purchasing. Choose the furniture according to your water resistance, load and usability requirements.
- Notification of warranty claim
- The warranty claim can be validated with the warranty card. In the event of non-provision of a warranty card, the conclusion of the contract shall be deemed proven if the proof of payment of the sale/purchase - an invoice or receipt issued on the basis of the Value Added Tax Act - is presented.
- In this case, the rights arising from the warranty can be enforced by proof of payment of the sale/purchase. You can enforce your warranty claim at the business unit. The obligation to fulfil the warranty obligation is obligation of the company, which based on the contract with you, is the service provider regarding the subject of the contract.
- After discovering the error, you must notify the company of the error without delay! An error reported within two months of the discovery of the error shall be deemed to have been reported without delay. You are responsible for any damage resulting from the delay in notification.
- When filing a quality complaint, the company is required to comply with Decree No. 19/2014 (IV.29.) on the rules of procedure for handling warranty and guarantee claims (hereinafter: the NGM Order), paragraph 4. The company is obliged to draw up a report with the content specified therein and to provide a copy of it to the consumer without delay and in a verifiable manner.
- If the company is not able to declare the fulfillment of the warranty claim at the time of its notification, it will notify you of its position within five working days.
- The company or the repair service (provider) is obliged to hand over a certificate according to paragraph 6 of the NGM Decree upon receipt of the product for repair.
- Procedure after claiming a warranty claim
- The repair or replacement shall be carried out within a reasonable period of time, taking into account the characteristics of the product and the intended use of the consumer in your best interests. The company will propose to carry out the repair or replacement within a maximum of fifteen days. During the repair, only new parts may be installed in the product.
- A product with a fixed connection or which weighs more than 10 kg or cannot be transported as a manual package on public transport, with the exception of vehicles, must be repaired at the place of operation. If repairs cannot be carried out at the place of operation, the company will take care of the removal and installation as well as the transport and return. The cost of fulfilling the warranty obligation must be paid by the company. If it is proven that the defect is not covered by the warranty, you will be responsible for all costs incurred in connection with the claim.
- Exclusion of warranty liability
- The defect is not covered by the warranty if the cause of the defect occurred after the delivery of the product to the consumer, especially in the following cases:
- Improper installation (unless the installation was carried out by the company or its agent, or if the improper installation is due to an error in the instructions for use),
 - Failure to maintain,
 - Improper use (other than the function of the furniture) (e.g. soaking),
 - Non-observance of the instructions for use, improper, not workmanlike handling, cleaning, care,
 - Use of care products with the wrong technology or cleaning agents with wrong chemical composition,
 - Repairing by an unprofessional, incompetent person,
 - Elemental damage, natural disasters, other atmospheric pollution, excessive solar radiation, excessive humidity,
 - Improper storage, external mechanical impact (damage, modification), electronic and physical overload,
 - Other reasons beyond the control of the manufacturer (e.g. cleaning).
- The warranty does not cover wear and tear due to natural use, as well as defects indicated on the warranty card, for which the consumer has received a price reduction, and in the case of washbasins and mirrors, faults within the curvature tolerance of surfaces specified in the document issued by the manufacturer.
- In the event of a consumer dispute, you can also initiate the proceedings of a conciliation body operating alongside the county (capital) chambers of commerce and industry.

IT MUST BE FILLED IN IN CASE OF REPAIR!

Time of claim request		
Time of receipt for repair		
Reason of fault		
Method of repair		
Time of return		